



Blow Out Preventer Box (BOP)

Installation Guide

1. The BOP will be sent assembled with the rubber. The BOP Box is mounted to the existing chute at the rear of the load point. The back of the existing chute or chute extension should have a straight edge where the BOP will be mounted. The BOP sides should be on the same plane as the existing chute sides and once in place should be seam welded to the existing chute extension or chute back. It may be necessary to modify the back of the existing chute or the BOP sides to obtain the correct fit.

Note: The length of the BOP Box will be determined by the amount of space between the existing chute and the tail pulley guard. If space permits an inspection door may be installed to the top cover of the BOP Box.

Note: These are typical installation guidelines and should be followed. However, these guidelines may have to be modified at times to allow for the variances in chute design. Each job has to be examined to determine appropriate installation.