



MATERIAL CENTERING PLATES

As the material is loaded onto the belt it will settle within the trough of the belt. If there is a slight surge of material or the material settles out along the edge of the belt some spillage may occur when the material leaves the chute extension or at the head chute where the belt flattens out.

This spillage can be eliminated by installing DCI Material Centering Plates. These plates are installed inside the chute extension and will roll the material in towards the center of the belt before it leaves the chute.